





Elmak srl  
Via SS. Grisante e Daria, 70  
42124 - Reggio Emilia - Italy

MODEL **PPE 4156**

VERSION **STD PRO**








**ELMAK**  
INDUSTRIAL AUTOMATION TECHNOLOGY

Elmak srl  
Via SS. Grisante e Daria, 70  
42124 - Reggio Emilia - Italy

MODEL **PPE 4156**





VERSION **INOX PRO**



**ELMAK**  
INDUSTRIAL AUTOMATION TECHNOLOGY

Elmak srl  
Via SS. Grisante e Daria, 70  
42124 - Reggio Emilia - Italy

MODEL **PPE 4185**  
VERSION **STD PRO**








**ELMAK**  
INDUSTRIAL AUTOMATION TECHNOLOGY

Elmak srl  
Via SS. Grisante e Daria, 70  
42124 - Reggio Emilia - Italy

MODEL **PPE 4185**






VERSION **INOX PRO**



Elmak srl  
Via SS. Grisante e Daria, 70  
42124 - Reggio Emilia - Italy

MODEL **PPE 419**






VERSION **STD PRO**



Elmak srl  
Via SS. Grisante e Daria, 70  
42124 - Reggio Emilia - Italy

MODEL **PPE 419**






VERSION **INOX PRO**



Elmak srl  
Via SS. Grisante e Daria, 70  
42124 - Reggio Emilia - Italy

MODEL **PPE 4215**

VERSION **STD PRO**



Elmak srl  
Via SS. Grisante e Daria, 70  
42124 - Reggio Emilia - Italy

MODEL **PPE 4240**

VERSION **STD PRO**